



OWNER'S MANUAL AND INSTALLATION INSTRUCTIONS

For All Models

TABLE OF CONTENTS

INTRODUCTION	3
WARNINGS	3
INSTALLATION PROCEDURES	4
НІТСН	4-5
BLADE ASSEMBLY	5-6
POWER CABLES	7
CONTROL HARNESS	8
HYDRAULICS	9
WIRING SCHEMATICS	10-11
LIGHT BAR	12
USER'S GUIDE	13
ADJUSTMENTS	13
ATTACHING/DETACHING	13
WARRANTY	14
REGISTRATION FORM	15

In an attempt to continually improve product performance and customer service, OMEGA ENGINEERING CONCEPTS, INC. reserves the right to modify construction, design, methods, and /or literature without prior notice. Consequently, equipment, specifications, and/or procedures contained within this manual may differ slightly from prior and/or future applications.